






HDMOD-6S Quick start guide



4-step installation guide

The HDMOD-6S can be programmed on the field using the following simple 4 steps*:

1st Step

Power up the HDMOD-6S by adding the external power supply. The HDMOD-6S will need 20-30secs to initialize itself. The SSD (Seven Segment Display – No 2) depicts the initialization status.

2nd Step

Choose "*Chanel mode*" by pressing the Channel/Profile button (No 1) and select the output RF channel using the Up/Downs buttons.

3rd Step

Choose "Attenuation mode" by pressing the Channel/Profile button (No 1) and select output attenuation (0dB, -10dB, -25 dB) using the Up/Downs buttons.

4th Sten

Choose "*Profile* mode" by pressing the Channel/Profile button (No 1) and select Profile number using the Up/Downs buttons. Each modulator must have its unique profile number in the same CATV installation.

For example, select:

Profile No 1 for the first modulator Profile No 2 for the second modulator

. . .

Profile **No10** for the 10th modulator etc...

^{*}The HDMOD-6S offers advanced programming features from a PC software via a USB interface.

More information

- You can download HDMOD-6S's full manual and software for advanced programming from product's page at www.lemco.gr.
- After 5 min the HDMOD-6S's keypad will be locked. To unlock, keep the "Up/Down" buttons (No.3) pressed simultaneously for 5sec. approximately.



This product complies with the relevant clauses of the European Directive 2002/96/EC. The unit must be recycled or discarded according to applicable local and national regulations.



Equipment intended for indoor usage only.



Conforms with the essential requirements of the EMC Directive 2004/108/EC the Safety Directive 2006/95/EC and 2001/65/EU RoHS Directive, based on the following specifications applied:

EU Harmonized Standards:

EN 55103-1: 2009 EN 55013-2: 2009

EN 60950-1:2006 + A12:2011

EN 62479: 2010

Contact Information

Lemco

 Latheas 46 - 13678
 Tel: +30 210 2811401

 Athens - Greece
 Fax: +30 210 2825755

 www.lemco.gr
 Email: info@lemco.gr